

## **Product Description**

FX Hoardings Paint is a matt, non-reflective, hard-wearing 100% acrylic paint, specifically formulated for painting construction hoardings and industrial ceilings to hide cables and air-conditioning duct work.

FeaturesBenefitsWater-based2-hour recoatHigh opacityEasy clean-up

Uses

FX Hoardings is used for hoardings and industrial ceilings.

Colour: Standard black.

#### **Surface Preparation**

All surfaces must be thoroughly cleaned and free of dirt, dust, grease, loose or flaking paint. Efflorescence or mould on masonry or concrete surfaces must be treated. Flatten gloss surfaces by thoroughly sanding back to surface prior to painting. Wipe clean with a damp cloth.

### **Application**

Stir contents thoroughly before and during use with a broad, flat stirrer, using an upward action.

Brush/Roller: Apply using a 75 mm brush or a 20 mm nap roller.

Airless/Conventional Spray: Suitable for application using all standard spray equipment.

**Approximate Spreading Rate**: 8–12 square metres per litre on unpainted surfaces and up to 16 square metres per litre on previously painted surfaces, depending on application technique and surface roughness.

Requires: 1–2 coats.

Thinner: Water, up to 10% if required.

Tinting: N/A.

**Method:** Brush, roller or airless/conventional spray equipment.

**Shelf Life**: 12 months.

**Drying Times** (at 25 °C): **Touch**: 2 Hours; **Recoat**: 4 Hours.

Note: Do not apply paint if the air temperature or substrate temperature is below 10 °C or above 35 °C. The temperature

should not fall below 10 °C during the drying process.

Clean-up: Water. Safety: Dust Mask. Gloss level: Less than 5% at a 60° viewing angle.

# Safety and Environmental Care

Safety

**Personal Protection:** Wear eye protection and dust mask when spraying, as splashes may cause eye irritation and inhalation of spray mist may cause respiratory irritation.

**Asbestos cement sheeting:** Do not disturb, sand or scrub, and avoid any peripheral dust. If you do not have professional expertise in the handling/removal of asbestos sheeting, use a licensed asbestos removalist.

Refer to product labels, current FX Australia Safety Data Sheets or call FX Australia for detailed information.

### Clean-up

Slippery when spilled • Restrict access to area until clean-up is completed • When cleaning up spills, use personal protection equipment • Stop leak if safe to do so and contain spill with absorbent material such as sand, vermiculite or other inert material • Prevent spill from entering waterways • Collect and dispose of spilled material according to local regulations • Wash away remnants with liberal amounts of cold water.

### Storage

Store in a cool, dry, well-ventilated place out of direct sunlight • Store away from strong acids and moisture • Keep containers closed at all times and check regularly for spills.

## Disposal

Refer to State/Territory Land Waste Management Authority: most authorities permit disposal at approved land waste sites.

Date of Issue: Updated June 2019